

STR-H711 BOARD HEADER ASSIGNMENTS

EXT1			EXT2			
P0.1	1	0	P0.0	38	39	nRST
P0.3	3	2	P0.2	36	37	3.3V
P0.5	5	4	P0.4	34	35	STB
P0.7	7	6	P0.6	32	33	1.8V
P0.9	9	8	P0.8	30	31	P1.15
P0.11	11	10	P0.10	28	29	CLK
P0.13	13	12	P0.12	26	27	DP
P0.15	15	14	P0.14	24	25	P1.9
P1.1	17	16	P1.0	22	23	P1.7
P1.3	19	18	P1.2	20	21	P1.5
				GND		
				5V-USB		
				BOOTEN		
				V1.8BKP		
				P1.14		
				DN		
				P1.10		
				P1.8		
				P1.6		
				P1.4		

The pin numbers are printed on the top silkscreen, the above drawings are with TOP view of the board
 The distance between the headers is 1"